

INSTALLATION MANUAL














Do not operate with power supply connected.

AC220-240V | 50/60Hz | IP20 | Die cast







Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.